

## Installation Instructions

- Make sure the floor around the host bollard is completely level, flat and clear of debris.
- Unpack bollard covers and hardware. Partially drive the three set screws in the holes provided to engage threads. See figure below. Make sure the hex drive end of the set screw is facing the outside of the bollard cover.
- Drape the required foam strips over the top of the host bollard in a cross configuration and cut off ends 6 inches above the floor surface.
- Slide the bollard cover over the spacer strips and host bollard until the bottom of the bollard cover seats on the floor surface.
- Drive each of the three hex drive set screws equally until each engages the host bollard. Firmly tighten all of the set screws so they do not project from the outside surface of the bollard cover. Be careful not over-tighten the set screws and deform the sides of the bollard cover. Installation is complete. Leave plastic wrapping in place for protection, coordinate with GC.

