13046 Racetrack Road | Suite 177 | Tampa, FL 33626 813.343.5979 | info@FenWalls.com | www.FenWalls.com FenWall - 3 Part Specification Manufactured Metal Bollards Bollard Covers 32 39 13

## **PART 1 GENERAL**

### 1.01 SUMMARY

- A. Section Includes: Stainless Steel Bollard Covers.
- B. Related Sections:
  - 1. Section 05 50 00 Metal Fabrications
  - 2. Section 32 17 13 Parking Bumpers
  - 3. Section 34 71 13 Vehicle Barriers

### 1.02 REFERENCES

A. ASTM – American Society for Testing and Materials

## 1.03 SUBMITTALS

A. Per Division 1, Product Information, Samples, Shop Drawings and Copy of Warranty.

#### 1.04 WARRANTY

- A. Manufacturer's Warranty:
  - 1. Warranty Period: Manufacturer's one (1) year standard warranty commencing on the substantial date of completion for the project provided that the warranty, in no event, shall start later than six (6) months from the date of shipment.
  - 2. Conditional Warranty: Extended warranty periods may be issued at the manufacturer's discretion and must be approved at time of purchase.

# **PART 2 PRODUCTS**

## 2.01 MANUFACTURERS

A. FenWall, LLC 13046 Racetrack Road, Suite 177 Tampa, FL 33626 Telephone: (813) 343-5979

Telephone: (813) 343-5979

www.FenWalls.com

#### 2.02 MATERIALS

- A. Stainless Steel Pipe: ASTM 312, schedule 10, Type 304 stainless
- B. Stainless Steel Plate: ASTM A240, Type 304 stainless

#### 2.03 BOLLARD COVER

- A. Type: Bollard cover consisting of a metal sleeve with top cap and optional bottom trim plate for decorative applications.
- B. Bollard Cover: Fabricated from 4 inch, 5 inch and 6 inch schedule 10, type 304 stainless steel pipe and 1/8 inch thick 304 stainless steel plate with brushed finish. Top is rounded.
- C. Anchoring: (3) stainless steel set screws.

13046 Racetrack Road | Suite 177 | Tampa, FL 33626 813.343.5979 | info@FenWalls.com | www.FenWalls.com FenWall - 3 Part Specification Manufactured Metal Bollards Bollard Covers 32 39 13

# **PART 3 EXECUTION**

## 3.01 PREPARATION

A. Prior to fabrication, field verify required dimensions.

#### 3.02 INSTALLATION

- A. Install with neoprene foam strips per manufacturer's installation manual and approved shop drawings.
- B. Coordinate bollard cover work with work of other trades for proper time and sequence to avoid construction delays.
- C. Accurately fit, align, securely fasten and install free from distortion or defects.

# **END OF SECTION**